

Splicecom 
PCS proactive
communication
station



PCS 100 User Manual

What's New in Version 3

Call Cleared Operation

If a call is made or answered using the handset, when the distant end clears the call the Call Status will remain allowing you to pick up a parked call or allow you to make another call by pressing the Speaker icon. Replace your handset if this is not required.

Message Waiting Indicator

Message Waiting Indicator LED will flash to indicate the status of the phone as follows:

- Dialling – on
- Alerting – flash 250/250 mSec
- Busy – flash 500/250 mSec
- Hold – flash 250/2000 mSec
- Connected – on
- Call Waiting – flash 250/250 mSec

Terminology Changes

In order to ensure consistency across all User manuals the following terminology has been changed.

Old Name	New Name
Context Sensitive Display	Call Status
Status Screen	Call Status
Display	Call Status
Favourites entry	Speed Dial
Last Number Redial button	Redial button
Handsfree button	Speaker button
Message Box button	Messages button